


Make note of the small pins in the printer's printhead holder, and the small holes on the back of the printhead.

Small pins on the holder in the printer



Small holes in Printhead body.

Before Screw mounting the Printhead, make sure the Printhead holes catch the two small pins on printer.

You can very lightly feel the two pins click into position when the Printhead is correctly aligned in the printer.



Only after the printer pins click into the holes on the Printhead, screw in the Printhead.

